

# INSTALLATION INSTRUCTIONS

## Side Spray

**NEWPORT BRASS**  
Flawless Beauty. From Faucet to Finish.™

### Recommended Installation by a Professional Plumbing Contractor

**⚠ NOTE: NEVER CONNECT SIDE SPRAY HOSE DIRECTLY TO THE MAIN WATER SUPPLY.**

1. Remove MOUNTING KIT (1) from threaded shank of ESCUTCHEON (2) and SPRAY HOSE (3).
2. Drop SPRAY HOSE (3) and ESCUTCHEON (2) unit through mounting hole surface.
3. From underside of mounting surface, slide SPRAY HOSE (3) through MOUNTING KIT (1) and secure into place by threading MOUNTING KIT (1) onto shank of ESCUTCHEON (2).  
Use screwdriver to tighten 2 screws of MOUNTING KIT (1)
4. Thread SPRAY HOSE (3) into base of DIVERTER OUTLET (4).

