

WASTE & OVERFLOW DRAIN, LIFT & TURN STYLE INSTALLATION DIAGRAM MODEL No: 257



Recommended Installation by a Professional Plumbing Contractor

Note: The use of petroleum base plumbers putty on product will nullify warranty. We recommend the use of clear silicone sealing material.

