

INSTALLATION INSTRUCTIONS
HSND SHOWER HOLDER
MODEL NO. 296, 297

NEWPORT BRASS®
Flawless Beauty. From Faucet to Finish.™

Recommended Installation by a Professional Plumbing Contractor

1. Locate the desired position of holder on finished wall.
2. Mark wall and drill 5/16" hole for WALL ANCHOR (3).
3. Dis-assemble holder by removing the SETSCREW (5) and unthreading the end of HOLDER (6) from the BASE (1). See **Figure 1**.
4. With O-RING (4) at the bottom of the BASE (1) secure them to wall with SCREW (2) by tightening into WALL ANCHOR (3).
5. Re-assemble HOLDER (6) onto BASE (1) and secure with SETSCREW (5).
6. The HOLDER (6) should be installed in vertical position. See **Figure 2**.

