

Installation Instructions

Open Towel / Tissue Holder

Model No. 75-27

NEWPORT
365

Recommended Installation by a Professional Contractor

1. Drill hole in wall at desired location using the appropriate drill size:

- Wood Screw (#6 x 2") - use: 3/32" Drill
- Toggle Screw (6-32 x 3") - use: 3/8" Drill

2. Fasten BASE (1) to wall using either WOOD/TOGGLE SCREWS (2). (See Fig. 1)

3. Place POST (3) into BASE (1) at the appropriate height specified and secure into place with set SCREW(4). (See fig.2)

4. Place ESCUTCHEON (3) over BASE (1). Place POST (4) over ESCUTCHEON (3). Secure into place by tightening the SETSCREW (5). (See Fig. 2)

