


SINGLE HOLE LAVATORY FAUCET
INSTALLATION INSTRUCTIONS
Model No: 9208



NEWPORT BRASS
Flawless Beauty. From Faucet to Finish.™

2001 CARNEGIE AVE, SANTA ANA CA 92705

(949) 417-5207

WWW.NEWPORTBRASS.COM

Recommended Installation by a Professional Plumbing Contractor

Note: The use of petroleum base plumbers putty on our products will nullify the warranty. We recommend the use of clear silicone sealing materials. Recommended deck thru hole \varnothing 1-3/8"

1. Place the spout hoses, one at a time, and secure spout into place with NIPPLE(1) and MOUNTING KIT(2). See Fig. 1
2. Attach hot/cold spout supply hoses to valves in the wall. See Fig. 2
3. Remove aerator from spout. Turn on water supply and flush system until water is clear. Check for leaks and make any final adjustments required. Re-attach aerator to the spout.




Figure 1




Figure 2

2001 CARNEGIE AVE, SANTA ANA CA 92705
(949) 417-5207