

# Single and Double Towel Bar / 2 & 3 Post Tissue Holder

## Installation Instructions

Model No. 10-01, 10-02, 10-04, 10-09, 10-28

Recommended Installation by a Professional Contractor

1. Using the table below, measure the appropriate distance between post centers. (See Fig. 1)

Note: Hole locations should be level.

- 18" Single Towel Bar - 18 1/8"
- 24" Single Towel Bar - 24 1/8"
- 30" Single Towel Bar - 30 1/8"
- 18" Double Towel Bar - 18 5/8"
- 24" Double Towel Bar - 24 5/8"
- Tissue Holder (2 Post) - 6 1/4"
- Tissue Holder (3 Post) - 6 1/4" (2x), (See Fig. 2)

2. Drill hole(s) in wall at points marked using the appropriate drill size:

- Wood Screw (#6 x 2") - use: 3/32" Drill
- Toggle Screw (6-32 x 3") - use: 3/8" Drill

3. Dis-assemble END POST (6) from POST (3). See Fig. 5. Remove ESCUTCHEON (5) from POST (3). See Fig. 4. Loosen SETSCREW (4) in FLANGE (1) and remove POST (3). Fasten FLANGE (1) to wall using either WOOD/TOGGLE SCREW (2). See Fig. 3.

4. Engage POST (3) into FLANGE (1). Position POST (3) height to 2 5/16" from mounting surface. Secure POST (3) into place with SETSCREW (4). See Fig. 3.

5. Thread ESCUTCHEON (5) onto POST (3). See Fig. 4.

**6a. Towel Bars (Single):** Assemble TOWEL BAR (7) between END POSTS (6). Slide END POSTS (6) onto POST (3) and secure into place with SETSCREW (4). See Fig. 5.

**6b. Towel Bars (Double):** Take the finished towel bar assemble and place END POSTS (6) onto POST (3). Secure into place with SETSCREW (4). See Fig. 6.

**6c. Tissue Holder (2 & 3 Post):** Place END POST (6) onto POST (3) and secure into place with SETSCREW (4). Place HOLDER (8) between END POST (6). See Fig. 7.

