

# Installation Instructions

## Single and Double Towel Bar / 2 & 3 Post Tissue Holder

### Model No. 75-01, 75-02, 75-03, 75-04, 75-05, 75-28, 75-29

Recommended Installation by a Professional Contractor

1. Using the table below, measure the appropriate distance between post centers. See Figure 1  
 Note: Hole locations should be level.

- 18" Single Towel Bar - 18 5/16"
- 24" Single Towel Bar - 24 5/16"
- 30" Single Towel Bar - 30 5/16"
- 18" Double Towel Bar: 18-11/16"
- 24" Double Towel Bar: 24-11/16"
- Tissue Holder (2 Post) - 6 1/4"
- Tissue Holder (3 Post) - 6 1/4" (2x), See Figure 2.

2. Drill hole(s) in wall at points marked using the appropriate drill size:

- Wood Screw (#10 x 1 3/4") - use: 1/8" Drill
- Toggle Screw (6-32 x 3") - use: 3/8" Drill

3. Fasten FLANGE (1) to wall using either WOOD/TOGGLE SCREWS (2). See Figure 3.

4. Place ESCUTCHEON (3) onto FLANGE (1). See Figure 4.

5a. **Towel Bars (Single):** Assemble TOWEL BAR (7) between END POST (5). Place END POST (5) onto FLANGE (1) and secure into place with SETSCREW (4). See Figure 5.

5b. **Towel Bars (Double):** Take towel bar assembly and place END POST (5) onto FLANGE (1). Secure into place with SETSCREW (4). See Figure 6.

5c. **Tissue Holder (2 & 3 Post):** Place END POST (5) onto FLANGE (1) and secure into place with SETSCREW (4). Place HOLDER (6) between END POST (5). See Figure 7.

