
INSTALLATION INSTRUCTIONS KITCHEN BRIDGE FAUCET WITH SIDE SPRAY



Model No's: 3220-5413



Congratulations on the purchase of this Newport Brass product, an excellent choice, that will give you years of quality service and enhance the look and style of your home.

Recommended Installation by a Professional Plumbing Contractor


Note: The use of petroleum base plumbers putty on our products will nullify the warranty. We recommend the use of clear silicone sealing materials. Use Plumbers tape or equivalent to seal all threaded joints. If mounting faucet to stainless steel rim, an under-mount support, (e.g. wood, appropriate size x I/2" thick), should be utilized.


Recommended deck hole \emptyset 1-3/8". Drill holes in mounting surface, center spacing for bridge faucet to be 8" and the side spray hole to be a minimum of 4-3/4" away from the nearest mounting hole of faucet.


- I. Do not remove white PLASTIC PROTECTOR. See Figure 1.
- 2. Place bridge faucet BODY onto mounting surface. Secure both sides in place with MOUNTING KIT. See **Figure 1**.
- 3. Attach the DIVERTER to cold side SHANK as follows: Reference Figure 2.
 - a. Rotate and align the pin groove of SHANK and the pin hole in DIVERTER.
 - b. Secure position by pushing QUICK RELEASE PIN through the pin hole and groove. See Figure 2.
 - c. Connect hot side HOSE to DIVERTER. See Figure 3.
- 4. Place the SIDE SPRAY ESCUTCHEON with SHANK through mounting surface and secure in place with MOUNTING KIT. See **Figure 3**.
- 5. Drop SIDE SPRAY hose through ESCUTCHEON and thread onto DIVERTER. See Figure 3.
- 6. Use 1/2 NPSM hoses (Not included) to Connect to water supply.
- 7. Remove AERATOR from spout, turn on water supply, and flush valves until water is clear. Check for leaks and make any final adjustments required. Re-attach AERATOR to the spout.

Important:

1. Faucet can operate without side spray by replacing the side spray connection to cold block with 1/4-18 NPMS or 1/4-18 NPT thread cap.







Adjust Handle Alignment:

- I. In **Figure 4**, ensure cartridges in full closed position and check HANDLE alignment. If the HANDLE is not correctly aligned, temporary remove the CAP, HANDLE and rotate CARTRIDGE ADAPTER one tooth clockwise, reassemble the HANDLE and recheck alignment. Repeat until the HANDLE is aligned and secure the HANDLE in place with ADAPTER SCREW.
- 2. Reattach the CAP.

